



Titan One Keyboard Shortcuts

F1 Move to other screen

F2 Activate window

F3 Minimise/Maximise

Shift F3 Next window

F4 Size/Position

Shift F4 Move to other screen

F5 Close window

Shift F5 Close all windows

F6 Open Playbacks window

F7 Open Fixtures window

F8 Open Groups window

F9 Open Colours window

F10 Open Positions window

F11 Gobos/Beams window

F12 Open Channel Grid

Esc Exit menu

Enter Enter

Alt 1 Softkey A

Alt 2 Softkey B

Alt 3 Softkey C

Alt 4 Softkey D

Alt 5 Softkey E

Alt 6 Softkey F

Alt 7 Softkey G

Alt ↑ F Fixture

Alt ↑ P Palette

Alt ↑ M Macro

Alt ↑ G Group

/ (num) Thro Alt

* (num) @ Alt → Next fixture

Ctrl X Cut text

Ctrl C Copy text

Ctrl V Paste text

Ctrl A Select all text

Ctrl Z Undo

Ctrl Y Redo

Alt C Clear

Alt R Record menu

Alt A Toggle Avo (shift) menu

Alt L Locate

Alt P Patch

Alt ↑ D Disk menu

Alt ↑ S System mode

Alt V Open/View menu

Alt G Go

Alt D Delete

Alt ↑ C Copy

Alt M Move

Alt U Unfold

Alt I Include

Alt ↑ R Release

Alt S Shape

Alt T Fixture Tools/ML Menu

Alt B Blind

Alt O Off

Alt F Fan

Alt ↑ O Attribute options

Alt ↑ L Latch menu

← Previous fixture

- (num) Not Alt ↑ All + (num) And Alt ↓ Highlight