


Mini Xtreme Beam

SH-2RB

USER MANUAL



CE

Congratulations on purchasing this 120W moving Beam Light
Thank you for extending your trust in our technology!

Voltage :110V/240V AC, 50/60Hz
Power Consumption:150W
Lamp:2R 120w (DMX on/off)
Lumen output:70000LM/10meter
Color Temperature:8000K
Lens:3-layer optic glass lens
Prism:8 Prism rotation
Gobo:Gobo wheel with 14 gobos
Colors:Color wheel with 13 colors,single rotation rainbow effect
DMX Channel:13CH
Control:Master-slave mode
DMX Mode:Auto mode
Head movement:Pan 540° (16bit) Electric correction
Tilt 270° (16bit) Electric correction
with auto-correction function

Focus :Double automatic focusing
Dimmer:Independent dimmer channel, 0-100% linear dimmer
Strobe:Independent strobe channel, 1-13times/s, speed adjustable
LAMP DMX ON/OFF: LAMP DMX ON/OFF, ignited by inverter, protect and lengthen the lifetime of the bulb
Other functions
Fixture and lamp usage time display
Highly Positioning precision
Adjustable fan speed
Built-in analyzer for easy fault finding, error messages
Input signal isolating protection

For reasons of safety and approval(CE) the personal reconstruction and/or modification of this product is prohibited.Please observe that damage caused by modifications performed manually to this device is not covered by the warranty.

This product leaves our works in a perfect condition.Please observe all notes in these operating instructions to warrant this condition and the safe operation of hte product!

Any damage caused as a result of the non-compliance with these operating instructions leads to the expiration of any warranty claim.The manufacturer does not accept liability for any damage to property or for personal injury resulting from the improper handling of the product,or non-observance of the operating instructions.

Store these operating instructions in a safe place for later reference and pass them to any new holder when selling or lending or leaving this device in the hands of any other party.

Application According to Purpose

This product is a lighting effect which creates specila light effects with one lamp.Togenerate these effects,the product must be connected to mains and a DMX-512 compatible controller.

This product is designed for AC110~240V/50~60Hz operation and exclusively for indoor use.

If used for any purpose other than described in these operating instructions,the device may suffer damage and the warranty expires.Also,any other use is linked with risks such as short circuits,fire,electrical shock,etc.

The manufacturer's serial number must never be removed as otherwise the warranty expires.

Notes on safety

1. Before Operation



ATTENTION:
DANGER OF LIFE! RISK OF FIRE!
RISK OF SHORT CIRCUIT!

Prior to the initial operation of this product, please do the followings

- Read these operating instructions with great care;
- Study and observe all instructions carefully;
- Ensure that everybody and anybody involved in the installation, operation, transport and storage of this product is suitably qualified;
- Verify whether any visible damage was caused during transport. If the power cord, housing or the light are damaged, do not operate the device; contact your specialized dealer immediately.

2. Supply Voltage, Mains Cord and Connection to Mains

The handling of supply voltage, mains cords and connections to mains calls for particular care considering the risk from a life-threatening electric shock, the risk of fire and the risk of short circuits please observe the following notes in particular:

Products operating on supply voltage should be kept out of the reach of children. Therefore ensure the permanent supervision if children are in the immediate vicinity of the product!

For commercial facilities the regulations on the prevention of accidents of the respective trade association must be observed. The operation of this equipment at schools, training facilities, and hobby or self-help workshops must be supervised responsibly by trained personnel.

Check the product regularly for any damage to the mains cord! Should you discover any damage to the mains cord, do not operate or disconnect this product! Secure the product against accidental operation and contact your specialized dealer.

Always separate the product from mains by holding the mains plug by the handling surface. Never disconnect by holding the line cord! Be sure to connect the product exclusively to AC 110-127V/50-60Hz!

Always insure during installation, operation, transport and when storing the product that the mains cord is not exposed to possible mechanical damage, or damage caused by humidity, fluids, heat or cold!

The products cable entry must not be exposed to stress from pull! Create the mains connection once the product has been installed only. Always connect the mains plug last!

The product must only be connected to a proper outlet of the public supply grid. Connect the mains cord to suitable outlets only! Use extensions cords in compliance with specifications only! Do not allow the mains cord to come into contact with other cords!

Ensure during installation, operation, transport and storage that none of the cables are freely exposed!

Never touch the mains cord, mains plug and outlet with wet or damp hands!

When not using the product, and prior to cleaning always disconnect the product from mains! To do so, hold the mains plug by the handling surface and never pull the mains cord!

Never connect the device to dimmer packer!

3. Housing



**ATTENTION:
DANGER OF LIFE! RISK OF FIRE!
RISK OF SHORT CIRCUIT!**

Always insure during installation, operation, transport and when storing the product that no shocks or other forces impact the housing!

The housing must not touch onto any other devices or objects during operation!

Easily flammable materials, e.g. decoration material and other surfaces and objects, must maintain a minimum distance of 3m to the housing! Walls must maintain a minimum distance of 50cm to the housing! The device must be installed on a fireproof surface only (no carpet)! Always ensure a proper circulation of air.

Do not touch the housing during operation it will heat up. The housing is safe to touch approx. 5 minutes following the end of operation!

The device must never be carried via the projector arms. Use the carrying handles only!

Fluids must not enter the housing as this could reduce the protective insulation and may

trigger short circuits which may lead to fatal electro shocks !If fluids have entered, disconnect the mains plug immediately and secure the product against unintentional operation and contact your specialized dealer! Damage caused as a re-suit of fluids entering the housing is exempt from warranty .

No metal parts or other items must enter the housing as this may reduce the protective insulation or trigger short circuits which may lead to fatal electric shocks !If metal parts or other items have entered ,disconnect the mains plug immediately,secure the product against unintentional operation and contact your specialized dealer!Damage caused by metal parts or other items in the housing is exempt warrantably.

4. Operating Environment



**ATTENTION:
DANGER OF LIFE ! RISK OF FIRE !
RISK OF SHORT CIRCUIT !**

The product must be operated and stored in a dry environment only !

Splash water ,rain,humidity,fog may reduce the protective insulation which may lead to fatal electric shocks!The limit value for relative humidity is 50% at 45°C.A minimum distance of 1.5m to a fog machine must be observed ;fog saturation in the room must not reduce the visibility to below 10m .

The product must be operated at a temperature range of between -5°C and 45°C only.Protect the product against direct exposure to sunlight or other heat,such as from radiators! If the product is taken from a cold environment into a warm environment it must only be taken into operation once it has reached ambient temperature,since the condensation created by the difference in temperature may destroy the device!

Protect the product against dust!Dust may reduce the protective insulation,which may cause fatal electric shocks!

The product must be operated at altitudes ranging between 20m below and 3000m above sea level only!

The product must not be operated during thunder storms;risk of destruction from surge voltages!

The product must be operated at a minimum distance of 1.5m to lit objects only!

5. Installation



**ATTENTION:
RISK OF SHORT CIRCUIT !**

This product can be operated suspended or as stand-alone system.

Should your lighting effect show any signs of damage,do not install the device!In this case,have your lighting effect repaired by your specialized dealer.The manufacturer does not accept responsibility or liability for damage to property or personal injury resulting from an improperly installation!

As a stand-alone system the device must be installed vertically on an absolute planar,firm,fireproof,shock and vibration-free surface.The installation of this lighting effect must be carried out by trained and professional staff!The installation of this lighting must only be carried out with the appropriate materials!

The suspended installation of this lighting effect necessitates a suitable suspension system!The lighting effect must never be fixed swinging freely in the room.No individuals should linger underneath the lighting effect during suspended installation!

It is a must to install this device with a second independent fixture.Such second fixture must guarantee in the event of failure of the main fixture that no assembly parts will fall down.Use the fixture on the undersurface only.

The light effect unit must be attached via two certified hooks and omega bracket to a tie-bar system.Use the screw threads on the undersurface only.


It must be ensured that an expert inspects the mechanical and safety-relevant installation prior to the initial operation and following major modifications, prior to the renewed operation. It must be ensured that an expert inspects the mechanical and safety-relevant installation at least once a year. It must be ensured that an expert inspects the mechanical installation and the installation of relevance to safety within the framework of an acceptance test at least every four years.

The installation fixture must be as such that it can withstand for a period of 60 minutes 10 times the load capacity without harmful deformation.

It is prohibited for any individual to unnecessarily stay or pass beneath the installation during any type of assembly work.

The light effect unit must be secured by a safety arrester cable if fly-mounted. The cable must withstand 12 times the weight of the light effect unit. Use arrester cables equipped with quick closing links. The dropping distance must not exceed 20 cm. Defect arrester cables or arrester cables that have already been exposed to stress must not be used.

6. Operation



Controls




Link all DMX devices with a DMX-512 controller by using a standard, 3-pin DMX cable. Connect the output of the first device with the input of the second device and the output of the second device with the input of the third device and so on.

Connect the mains plug to an outlet.

Operating the product for the first time may generate smoke and odour, this is not a defect. Avoid dis/connecting the product repeatedly and quickly from/with mains! Always wait 15 minutes prior to the next dis/connection!

The device starts not until a self-testing and starting time. If the moving head is ready to start, push and roll the function wheel. The LCD display shows the options, as below:

7. Lamps



During operation, the lamps will reach temperatures of up to 600°C. Touching the lamps may cause serious burns! Objects coming into contact with the lamps during and shortly after operation may catch fire!


Disconnect the product from mains prior to installing or before changing a lamp! Allow a lamp to cool for approx. 15 minutes before exchanging it!

Never touch a lamp with bare hands! If damaged or deformed, a lamp must be exchanged!

When exchanging the lamp be sure to use suitable lamps only. Lamps with greater performance generate excessive heat for the product, risk of fire! Damage resulting from the use of an unsuitable lamp is exempt from warranty!

Never connect the lighting effect to the mains prior with opened housing.


8. Fuse



Disconnect the product from the mains prior before changing a fuse.
 Only replace the fuse by a fuse of same type and rating! An incorrect fuse could damage or destruct the lighting effect.

Replace a fuse by levering the fuse holder cover with an appropriate screwdriver. Remove the old fuse and place the fuse inside the holder. Replace the fuse holder and insert it.
 Never connect the lighting effect to the mains prior with opened housing.

9. Cleaning



The product must be freed regularly from dust, other deposits and contamination as this may reduce the protective insulation, which may lead to a fatal electric shock!
 Before cleaning, always disconnect the product from mains!
 This product should be cleaned with a moist cloth only; never use aggressive cleaning agents, solvents or benzine for cleaning.

Ensure that the product is completely dry before operating it again after cleaning!



To avoid damage caused during transport, wrap the product in its original packaging only and handle it with great care during transport!

DMX Channel

DMX Chart

Mode/ Channel	Value	Function
St		
1		<u>PAN Movement 8bit</u>
	0-255	Pan Movement
2		<u>Pan Fine 16bit</u>
	0-255	Fine control of Pan movement
3		<u>TILT Movement 8bit</u>
	0-255	Tilt Movement
4		<u>Tilt Fine 16bit</u>
	0-255	Fine control of Tilt movement
5		<u>Speed pan/tilt movement</u>
	0-245	max to min speed
	246-255	no function
6		<u>Color Wheel</u>
	0-8	Open / white
	9-17	Color1

	18-26	Color2
	27-35	Color3
	36-44	Color4
	45-53	Color5
	54-62	Color6
	63-71	Color7
	72-80	Color8
	81-89	Color9
	90-98	Color10
	99-107	Color11
	108-116	Color12
	117-127	Color13
	128-189	Forwards rainbow effect from fast to slow
	190-193	No rotation
	194-255	Backwards rainbow effect from slow to fast
7		<u>Fixed gobos, cont. rotation</u>
	0-7	Open
	8-15	Rot. gobo 1
	16-23	Rot. gobo 2
	24-31	Rot. gobo 3
	32-39	Rot. gobo 4
	40-47	Rot. gobo 5
	48-55	Rot. gobo 6
	56-63	Rot. gobo 7
	64-71	Rot. gobo 8
	72-79	Rot. gobo 9
	80-87	Rot. gobo 10
	88-95	Rot. gobo 11
	96-103	Rot. gobo 12
	104-111	Rot. gobo 13
	112-119	Rot. gobo 14
	120-126	Rot. gobo 1 shake
	127-133	Rot. gobo 2 shake
	124-140	Rot. gobo 3 shake
	141-147	Rot. gobo 4 shake
	148-154	Rot. gobo 5 shake
	155-161	Rot. gobo 6 shake
	162-168	Rot. gobo 7 shake
	169-175	Rot. gobo 8 shake
	176-182	Rot. gobo 9 shake
	183-189	Rot. gobo 10 shake
	190-196	Rot. gobo 11 shake
	197-203	Rot. gobo 12 shake
	204-210	Rot. gobo 13 shake

	211-217	Rot. gobo 14 shake
	218-255	Fixed gobo wheel cont. rotation slow to fast
8		<u>Rotating prism, Prism / Gobo macros:</u>
	0-127	Open
	128-255	8 facet prism
9		<u>Rotating prism:</u>
	0-7	No rotation
	8-127	Forwards prism rotation from fast to slow
	128-135	No rotation
	136-255	Backwards prism rotation from slow to fast
10		<u>Focus :</u>
	0-255	Continuous adjustment from far to near
11		<u>Shutter, strobe:</u>
	0-31	Shutter closed
	32-63	No function (shutter open)
	64-95	Strobe effect slow to fast
	96-127	No function (shutter open)
12		<u>Dimmer intensity:</u>
	0-255	Intensity 0 to 100%
13		<u>Lamp on/off, reset, internal programs:</u>
	0-15	No function
	16-31	Lamp on
	32-47	Lamp switch off
	48-63	All motor reset
	64-79	scan motor reset
	80-95	Other motor reset
	96-111	Color change to any position
	112-127	gobo change to any position
	128-143	Internal program 1
	144-159	Internal program 2
	160-175	Internal program 3
	176-191	Internal program 4
	192-207	Internal program 5
	208-223	Internal program 6
	224-239	Internal program 7
	240-255	No function

Total Power: 150W

Fuse: 3A/240V

Step Motor: 13 PCS

Body Size: 45*31*25cm

Net Weight: 10Kg